

OceanSilk

Lipid Mimetic Serum

OCEANTHIX™
OCEANBOOST™

OceanSilk

Serum

OceanSilk is a high-performance, water-based serum that provides an oil-free *lipid mimetic* sensory profile. By leveraging the rheological synergy of Guar, Xanthan and OCEANTHIX™ LV, the formula achieves a silky not slimey, refined, non-tacky texture that mimics the silkiness and glide of a face oil without the use of lipids or silicones.

The formulation serves as a bio-based sensorial vehicle for OCEANBOOST™ LF, delivering a multifunctional approach to skin health. The ingredient was validated *in vitro* and this formulation *in vivo*:

- **Skin Longevity:** Supports the ECM to achieve long-term resilience by modulating the AP-1 pathway.
- **Barrier Recovery:** Reduces TEWL and improves hydration by encouraging cellular migration and accelerating the natural repair cycle.
- **Reactive Skin Relief:** Clinically proven to reduce redness and improve skin comfort for sensitive and hyper-reactive skin types.
- **Pigment Prevention:** Provides a proactive solution to stop the formation of hyperpigmentation and PIH before it becomes visible.

To ensure maximum tolerance, the serum was patch-tested on 20 subjects with sensitive skin.

ORIGIN[®]OCEAN

*lipid mimetic feel without
the use of oils or silicones*

OceanSilk

HYDRA
ALGIN
FROM

Stability	Compatibility	Description
5°C/RT°/45°C: 12 weeks	PP Lab Specimen Container	Translucent - milky fluid gel
Freeze-Thaw: 3 cycles	80% PCR Glass + Mono PP Dropper Parigi Mono Dropper Make-Up 30 mL Bottle Eurovetrocap	800 - 1000 cPs Rotational Viscometer Spindle 3 20 RPM
pH range: 5 - 5.5		

ORIGIN[®]
OCEAN

At Origin, the Ocean
is not for retail sale.

ORIGIN[®]
OCEAN

OceanSilk

Serum C020525EMD-2

- Load phase **A** into the main vessel. Mix until homogeneous.
- Premix **B** into a slurry. Add to **A** and mix 800 - 1000 RPM for 10 - 20 minutes.
- Premix **C** into a slurry. Add to **AB** and mix 800 - 1000 RPM for 10 - 20 minutes.
- Add **D** and mix until homogeneous.

Check pH; use Citric Acid/Sodium Hydroxide solution to adjust pH to 5 - 5.5, then QS to 100%

			%
A	DI Water		QS
A	Evicare® complex 3	Evident Ingredients	0.1 %
A	Evicide® G5 Eco	 Evident Ingredients	2.0 %
B	Glycerin		1.5 %
B	AURIST™ GHI	IFF	0.4 %
C	Evicide® propanediol	Evident Ingredients	3.0 %
C	OCEANTHIX™ LV	 Origin by Ocean	0.3 %
C	Evicare® aquatex 14	Evident Ingredients	0.1 %
C	OCEANBOOST™ LF	 Origin by Ocean	0.3 %
D	Evicide® levanise 1388	Evident Ingredients	3.0 %